



JXi™ Heater (Mfg. 2014–Present)

Key No.	Part No.	Description	Model No.
1	R0592400	Heater Jacket Top (No User Interface)	200,260,400
2	R0592500	Corner Posts, Heater Jacket, 4/PK	200,260,400
3	R0592600	Heater Base Replacement Kit	200,260,400
4	R0592700	Front/Back Panel, Heater Jacket	200,260,400
5	R0592900	Side Panel Kit, 2/PK	200,260,400
6	R0593100	Vent Terminal Housing Kit	200,260,400
N/S	R0593200	Brackets and Isolator Kit	200,260,400
7	R0593300	Jacket Hardware Kit (Nuts, Screws & Clips)	200,260,400
8	R0593400	Anchor Brackets	200,260,400
9	R0591800	Gas Inlet and Electric Hole Plug Kit	200,260,400


N/S-Not shown

JXi™ Heater (Mfg. 2014–Present)




Key No.	Part No.	Description	Model No.
10	R0590200	Exhaust Elbow Assembly	200,260,400
11	R0590400	Band Clamp Replacement Kit	200,260,400
12	R0590500	Refractory Replacement Kit, Internal	200,260,400
13	R0590700	Combustion Chamber Shelf Kit	200,260
14	R0590800	Combustion Chamber Lid (Gaskets and O-Rings)	200,260,400
15	R0590900	Gasket Kit	200,260,400
16	R0305400	Sight Glass Kit	200,260,400
17	R0457502	Igniter Kit	200,260,400
18	R0591000	Refractory Replacement Kit, External	200,260,400
19	R0593200	Isolator Kit	200,260,400
20	R0589405	Heat Exchanger Tube Replacement (400k)	400
	R0589403	Heat Exchanger Tube Replacement (260k)	260
	R0589402	Heat Exchanger Tube Replacement (200k)	200
	R0746905	Heat Exchanger CuNi Tube Replacement (400k)	400NN, 400PN
21	R0805805	Heat Exchanger and Header Assembly* (Excludes Burner)	400
	R0805803	Heat Exchanger and Header Assembly* (Excludes Burner)	260

* Complete Heat Exchanger and Header Assembly labeled for use on Natural Gas Heaters, kit includes labeling for use on LP Heaters

JXi™ Heater (Mfg. 2014–Present)


Key No.	Part No.	Description	Model No.
21	R0591100	Blower Assembly	200,260,400
22	R0591200	Air Intake Grate	200,260,400
	R0591302	Orifice, Blower Air Intake Kit, 200N	200
	R0591303	Orifice, Blower Air Intake Kit, 260N	260
	R0591305	Orifice, Blower Air Intake Kit, 400N	400
23	R0591312	Orifice, Blower Air Intake Kit, 200P	200
	R0591313	Orifice, Blower Air Intake Kit, 260P	260
	R0591315	Orifice, Blower Air Intake Kit, 400P	400
	R0591601	Gas Orifice Kit, 200, NAT (LP to NAT Conversion)	200
	R0591602	Gas Orifice Kit, 260, NAT (LP to NAT Conversion)	260
	R0591604	Gas Orifice Kit, 400, NAT (LP to NAT Conversion)	400
24	R0591605	Gas Orifice Kit, 200, LP (NAT to LP Conversion)	200
	R0591606	Gas Orifice Kit, 260, LP (NAT to LP Conversion)	260
	R0591608	Gas Orifice Kit, 400, LP (NAT to LP Conversion)	400
25	R0591400	Gas Valve	200,260,400
	R0591702	Burner Gas Supply System Kit, 200	200
26	R0591703	Burner Gas Supply System Kit, 260	260
	R0591705	Burner Gas Supply System Kit, 400	400
27	R0614500	Capacitor Blower, JXi Kit	200,260,400

JXi™ Heater (Mfg. 2014–Present)



Key No.	Part No.	Description	Model No.
28	R0589600	Access Door Kit (Door, O-Ring Seal, Screws)	200,260,400
29	R0589700	Thermal Regulator Valve	200,260,400
30	R0589800	Bypass Kit (Shaft, Spring, C-clip, Poppet)	200,260,400
31	R0446000	Drain Plug	200,260,400
32	R0589500	Gasket & Seals Kit (Heater Manifold)	200,260,400
	R0590005	Manifold Backplate, JXi 400	400
33	R0590003	Manifold Backplate, JXi 260	260
	R0590002	Manifold Backplate, JXi 200	200
34	R0590100	Manifold, Heater 3 Port (No Backplate)	200,260,400
36	R0593500	Goody Bag Kit*	200,260,400
37	R0522900	Universal Half Unions, 1/2PK	200,260,400
38	SEAQL1001	Sweep Elbow AquaLink® Temp	200,260,400
39	R0523000	Drain Cap Assembly	200,260,400
40	R0336101	Pressure Relief Valve JXi Replacement Kit	200,260,400
41	R0457001	Pressure Switch w/Siphon Loop Kit	200,260,400
	R0725203	Flow Plate Assembly, JXi 400	400
42	R0725202	Flow Plate Assembly, JXi 260	260
	R0725201	Flow Plate Assembly, JXi 200	200
43	JXIVFKIT	JXi VersaFlo™ Integrated Bypass Assembly Kit	200,260,400

*Goody Bag Kit also includes the Installation and Operation Manual and the Universal Controller Quick Guide

JXi™ Heater (Mfg. 2014–Present)


Key No.	Part No.	Description	Model No.
42	R0456900	Ignition Control	200,260,400
43	R0456301	Transformer	200,260,400
44	R0591900	User Interface Kit	200,260,400
45	R0592000	User Interface Lid Kit	200,260,400
46	R0592100	Wiring Harness Kit	200,260,400
47	R0456400	Air Pressure Switch	200,260,400
48	R0524300	Vent Limit Switch - JXi Rev G* and Earlier	200,260,400
48	R0719400	Electronic Flue Sensor - JXi Rev H* and Later**	200,260,400
49	R0013203	Water Pressure Switch, 7 PSI, JXi	200,260,400
50	R0458200	Power Interface Board (PIB) - JXi Rev G* and Earlier	200,260,400
50	R0719500	Power Interface Board (PIB) - JXi Rev H* and Later**	200,260,400
51	R0458100	Power Distribution Board (PDB)	200,260,400
52	R0456500	Temperature Sensor Kit	200,260,400
53	R0592300	High-Limit Temp Sensors	200,260,400
54	R0457502	Igniter Kit, JXi	200,260,400
55	R0457701	JXi Power Interface Harness	200,260,400

*The JXi Revision can be identified by the first letter of the serial number found on the heater rating plate.

**To install on Rev G and Earlier JXi heaters, R0719400 and R0719500 must be replaced together.