



Legacy™ Model LRZE Pool/Spa Heater (Discontinued)



Legacy™ Model LRZE Pool/Spa Heater (Discontinued)



Parts list starts on next page.

Legacy™ Model LRZE Pool/Spa Heater (Discontinued)

Parts diagram on pages 158–159.

Key No.	Part No.	Description	Model No.
MAIN GAS ASSEMBLY			
1	R0468901	Burner Tray Assembly, NAT	125
	R0468902	Burner Tray Assembly, NAT	175
	R0468903	Burner Tray Assembly, NAT	250
	R0468904	Burner Tray Assembly, NAT	325
	R0468905	Burner Tray Assembly, NAT	400
	R0469001	Burner Tray Assembly, LP	125
	R0469002	Burner Tray Assembly, LP	175
	R0469003	Burner Tray Assembly, LP	250
	R0469004	Burner Tray Assembly, LP	325
	R0469005	Burner Tray Assembly, LP	400
2	R0469101	Burner Tray, Shelf Only	125
	R0469102	Burner Tray, Shelf Only	175
	R0469103	Burner Tray, Shelf Only	250
	R0469104	Burner Tray, Shelf Only	325
	R0469105	Burner Tray, Shelf Only	400
3	R0494500	Gas Valve, NAT	All
	R0494600	Gas Valve, LP	All
4	R0469700	Anti-Rotation Bracket	All
5	R0457501	Hot Surface Igniter	All
6	R0458601	Flame Sensor Rod	All
7	R0469800	Burner, Main	All
8	R0469901	Burner Manifold	125
	R0469902	Burner Manifold	175
	R0469903	Burner Manifold	250
	R0469904	Burner Manifold	325
	R0469905	Burner Manifold	400
9*	R0469200	Orifice Set, NAT, 0-3K ft.	All
	R0469300	Orifice Set, NAT, 3-6K ft.	All
	R0469400	Orifice Set, NAT, 6-10K ft. (US Only)	All
	R0469500	Orifice Set, LP, 0-5K ft.	All
	R0469600	Orifice Set, LP, 5-10K ft. (US Only)	All
10	R0495601	Manifold Assembly, NAT 0-3K ft.	125
	R0495602	Manifold Assembly, NAT 0-3K ft.	175
	R0495603	Manifold Assembly, NAT 0-3K ft.	250
	R0495604	Manifold Assembly, NAT 0-3K ft.	325
	R0495605	Manifold Assembly, NAT 0-3K ft.	400
	R0495701	Manifold Assembly, NAT, 3-6K ft.	125
	R0495702	Manifold Assembly, NAT, 3-6K ft.	175
	R0495703	Manifold Assembly, NAT, 3-6K ft.	250
	R0495704	Manifold Assembly, NAT, 3-6K ft.	325
	R0495705	Manifold Assembly, NAT, 3-6K ft.	400
	R0495801	Manifold Assembly, NAT, 6-10K ft. (US Only)	125
	R0495802	Manifold Assembly, NAT, 6-10K ft. (US Only)	175
	R0495803	Manifold Assembly, NAT, 6-10K ft. (US Only)	250
	R0495804	Manifold Assembly, NAT, 6-10K ft. (US Only)	325
	R0495805	Manifold Assembly, NAT, 6-10K ft. (US Only)	400
	R0495901	Manifold Assembly, LP, 0-5K ft.	125

Key No.	Part No.	Description	Model No.
10	R0495902	Manifold Assembly, LP, 0-5K ft.	175
	R0495903	Manifold Assembly, LP, 0-5K ft.	250
	R0495904	Manifold Assembly, LP, 0-5K ft.	325
	R0495905	Manifold Assembly, LP, 0-5K ft.	400
	R0496001	Manifold Assembly, LP, 5-10K ft. (US only)	125
	R0496002	Manifold Assembly, LP, 5-10K ft. (US only)	175
	R0496003	Manifold Assembly, LP, 5-10K ft. (US only)	250
	R0496004	Manifold Assembly, LP, 5-10K ft. (US only)	325
	R0496005	Manifold Assembly, LP, 5-10K ft. (US only)	400
ELECTRICAL SYSTEM			
11	R3008800	Universal Control User Interface	All
12	R0496700	Universal Control w/ Bezel	All
13	R0470200	Universal Control Power Interface	All
14	R0061100	Transformer	All
15	R0456500	Temperature Sensor (Regular)	All
16	R0477300	Temperature Sensor (Salt)	All
17	R0456600	Gasket, Temperature Sensor	All
18	R0523900	Nut, Sensor Retainer	All
19	R0455400	Cap Sensor/Press Switch w/ O-Ring	All
20	R0013200	Pressure Switch, 2 PSI	All
21*	R0015500	Pressure Switch, 1-10 PSI	All
22	R0483600	Water Pressure Switch Tubing	All
	R0483601	Water Pressure Switch Tubing, reversed, Replacement Kit	All
23	R0457400	High-Limit Switch Assembly	All
24	R0457200	High-Limit Set (130°F and 150°F)	All
25	R0457300	High-Limit Switch, 130°F	All
26	R0023000	High-Limit Switch, 150°F	All
26A	R0456800	High-Limit Plug, 3/PK	All
27	R0491300	Ignition Control	All
28	R0012200	Fusible Link Assembly	All
29	R0337200	Fusible Link Bracket	All
30*	R0470000	Wire Harness, Set	All
VENT SYSTEM			
31	R0470301	Top Enclosure	125
	R0470302	Top Enclosure	175
	R0470303	Top Enclosure	250
	R0470304	Top Enclosure	325
	R0470305	Top Enclosure	400
32	R0470401	Vent Cover	125
	R0470402	Vent Cover	175
	R0470403	Vent Cover	250
	R0470404	Vent Cover	325
	R0470405	Vent Cover	400

Continued on next page.

Legacy™ Model LRZE Pool/Spa Heater (Discontinued)

Parts diagram on pages 158–159.

Key No.	Part No.	Description	Model No.
33	R0478201	Rainshield (Partition)	125
	R0478202	Rainshield (Partition)	175
	R0478203	Rainshield (Partition)	250
	R0478204	Rainshield (Partition)	325
	R0478205	Rainshield (Partition)	400
34	R0470501	Flue Collector Assembly	125
	R0470502	Flue Collector Assembly	175
	R0470503	Flue Collector Assembly	250
	R0470504	Flue Collector Assembly	325
	R0470505	Flue Collector Assembly	400
35	R0491601	Outdoor Vent Cap	125
	R0491602	Outdoor Vent Cap	175
	R0491603	Outdoor Vent Cap	250
	R0491604	Outdoor Vent Cap	325
	R0491605	Outdoor Vent Cap	400
36	R0499601	Indoor Draft Hood	125
	R0499602	Indoor Draft Hood	175
	R0499603	Indoor Draft Hood	250
	R0499604	Indoor Draft Hood	325
	R0499605	Indoor Draft Hood	400
37	R0478301	Adapter Plate	125
	R0478302	Adapter Plate	175
	R0478303	Adapter Plate	250
	R0478304	Adapter Plate	325
	R0478305	Adapter Plate	400
38*	R0500200	Clip	All
38A	R0534800	Fusible Link Assembly, Vent	All
38B	R0524300	Fusible Link, Vent, 240°C	All
WATER SYSTEM-POLYMER			
39	R0470800	Inlet/Outlet Header Assembly, Polymer	All
40	R0454201	Return Header Assembly, Polymer	All
41*	R0454500	Header Hardware Set, Polymer	All
42	R0470601	Heat Exchanger Assembly, Complete	125
	R0470602	Heat Exchanger Assembly, Complete	175
	R0470603	Heat Exchanger Assembly, Complete	250
	R0470604	Heat Exchanger Assembly, Complete	325
	R0470605	Heat Exchanger Assembly, Complete	400
	R0500701	Heat Exchanger Assembly, Complete, CuNi	125
	R0500702	Heat Exchanger Assembly, Complete, CuNi	175
	R0500703	Heat Exchanger Assembly, Complete, CuNi	250
	R0500704	Heat Exchanger Assembly, Complete, CuNi	325
	R0500705	Heat Exchanger Assembly, Complete, CuNi	400
43	R0446000	Heat Exchanger Drain Plugs, 2/PK Polymer	All
44	R0454000	3" Coupling Nut Kit w/ O-Ring	All
N/S	R0454100	O-Ring, Coupling, 2/PK	All
45	R0453701	Bypass Assembly, Polymer	All
46	R0453900	Bypass Spring, Adjustable, Polymer	All
47	R0449000	Tailpiece w/ Union Nut, 2/PK Polymer	All

Key No.	Part No.	Description	Model No.
WATER SYSTEM-BRONZE			
48	R0476601	Inlet/Outlet Header Assembly, Bronze, 2"	125
	R0476602	Inlet/Outlet Header Assembly, Bronze, 2"	175
	R0476603	Inlet/Outlet Header Assembly, Bronze, 2"	250
	R0476604	Inlet/Outlet Header Assembly, Bronze, 2"	325
	R0476605	Inlet/Outlet Header Assembly, Bronze, 2"	400
49	R0476700	Return Header Assembly, Bronze (includes set of 9 gaskets)	All
50	R0476801	Bypass Assembly, Bronze	125
	R0476802	Bypass Assembly, Bronze	175
	R0476803	Bypass Assembly, Bronze	250
	R0476804	Bypass Assembly, Bronze	325
	R0476805	Bypass Assembly, Bronze	400
51	R0476901	Bypass Spring, Bronze	125
	R0476902	Bypass Spring, Bronze	175
	R0476903	Bypass Spring, Bronze	250
	R0476904	Bypass Spring, Bronze	325
	R0476905	Bypass Spring, Bronze	400
52	R0011400	Bypass Gasket, Bronze	All
53	R0477200	Heat Exchange Hardware Kit, Bronze	All
54	R0477400	Temp Sensor Mounting Bracket, Bronze	All
55	R0477501	Water Pressure Switch Tubing, Bronze	All
	R0483601	Water Pressure Switch Tubing, Reversed	All
56	R0461500	Flange & Gasket Kit, Bronze	All
57	R0477800	Flange Bolts, Bronze	All
58	R0477900	3/4" NPT Plug, Bronze	All
59	R0478000	Header, Drain Plug, Bronze	All
60	R0470701	Heat Exchanger Assembly, Bronze, Complete	125
	R0470702	Heat Exch. Assembly, Bronze, Complete	175
	R0470703	Heat Exch. Assembly, Bronze, Complete	250
	R0470704	Heat Exch. Assembly, Bronze, Complete	325
	R0470705	Heat Exch. Assembly, Bronze, Complete	400
	R0500801	Heat Exch. Assembly, Bronze, Complete, CuNi	125
	R0500802	Heat Exch. Assembly, Bronze, Complete, CuNi	175
	R0500803	Heat Exch. Assembly, Bronze, Complete, CuNi	250
	R0500804	Heat Exch. Assembly, Bronze, Complete, CuNi	325
	R0500805	Heat Exch. Assembly, Bronze, Complete, CuNi	400

Continued on next page.

Legacy™ Model LRZE Pool/Spa Heater (Discontinued)

Parts diagram on pages 158–159.

Key No.	Part No.	Description	Model No.
WATER SYSTEM-ALL			
61	R0454300	Header Gasket Assembly (Set of 16)	All
62*	R0453800	Bypass Hardware, Gaskets	All
63	R0490101	Heat Exchanger Tube Assembly, Copper	125
	R0490102	Heat Exchanger Tube Assembly, Copper	175
	R0490103	Heat Exchanger Tube Assembly, Copper	250
	R0490104	Heat Exchanger Tube Assembly, Copper	325
	R0490105	Heat Exchanger Tube Assembly, Copper	400
64	R0490301	Heat Exchanger Tube Assembly, CuNi	125
	R0490302	Heat Exchanger Tube Assembly, CuNi	175
	R0490303	Heat Exchanger Tube Assembly, CuNi	250
	R0490304	Heat Exchanger Tube Assembly, CuNi	325
	R0490305	Heat Exchanger Tube Assembly, CuNi	400
65*	R0500001	Baffles, Heat Exchanger	125
	R0500002	Baffles, Heat Exchanger	175
	R0500003	Baffles, Heat Exchanger	250
FIREBOX COMPONENTS			
66	R0494901	Combustion Chamber Panels	125
	R0494902	Combustion Chamber Panels	175
	R0494903	Combustion Chamber Panels	250
	R0494904	Combustion Chamber Panels	325
	R0494905	Combustion Chamber Panels	400
67	R0484000	Igniter Bracket w/ Shield	All
JACKET COMPONENTS			
68	R0470901	Door w/ Latch	125
	R0470902	Door w/ Latch	175
	R0470903	Door w/ Latch	250
	R0470904	Door w/ Latch	325
	R0470905	Door w/ Latch	400
69	R0334900	Latch Assembly	All
70	R0460300	Grommet, Sealing, 2"	All
71	R0491100	Button Plug, 7/8"	All
72	R0482301	Rear Panel Assembly	125
	R0482302	Rear Panel Assembly	175
	R0482303	Rear Panel Assembly	250
	R0482304	Rear Panel Assembly	325
	R0482305	Rear Panel Assembly	400
73	R0482400	Side Panel, Right	All
74	R0482500	In/Out Cover Panel, Top	All
75	R0482600	In/Out Cover Panel, Bottom	All
76	R0482700	Side Panel, Left	All
77	R0482800	Return Side Cover, Top	All
78	R0482900	Return Side Cover, Bottom	All
79	R0483101	Heat Shield	125
	R0483102	Heat Shield	175
	R0483103	Heat Shield	250
	R0483104	Heat Shield	325
	R0483105	Heat Shield	400

Key No.	Part No.	Description	Model No.
80	R0483201	Heat Deflector Guard, Front	125
	R0483202	Heat Deflector Guard, Front	175
	R0483203	Heat Deflector Guard, Front	250
	R0483204	Heat Deflector Guard, Front	325
	R0483205	Heat Deflector Guard, Front	400
81	R0483401	Rear Partition	125
	R0483402	Rear Partition	175
	R0483403	Rear Partition	250
	R0483404	Rear Partition	325
	R0483405	Rear Partition	400
82	R0483501	Heat Deflector Guard, Rear	125
	R0483502	Heat Deflector Guard, Rear	175
	R0483503	Heat Deflector Guard, Rear	250
	R0483504	Heat Deflector Guard, Rear	325
	R0483505	Heat Deflector Guard, Rear	400
83	R0483901	Controller Mounting Panel	125
	R0483902	Controller Mounting Panel	175
	R0483903	Controller Mounting Panel	250
	R0483904	Controller Mounting Panel	325
	R0483905	Controller Mounting Panel	400
84	R0491000	Weather Stripping	All
85	R0492800	Grommet, 7/8"	All
OPTIONAL COMPONENTS			
86*	R0471001	Non-Combustible Base	125
	R0471002	Non-Combustible Base	175
	R0471003	Non-Combustible Base	250
	R0471004	Non-Combustible Base	325
	R0471005	Non-Combustible Base	400
87*	R0040400	Press Relief Valve Kit, 75 PSI, Bronze	All
88*	R0336100	Press Relief Valve Kit, 75 PSI, Polymer	All
89*	R0335800	Touch-Up Spray Paint, Black and Pewter	All
90*	R0336000	Temp Rise Measurement Kit	All

NOTE: All hardware sets contain all pieces necessary for assembly, including gaskets. Gaskets and hardware are included in all kits that involve the removal of a gasket as part of the procedure to replace a part.

* Parts not shown on key view.

** Manifold kit includes installed orifices but does not include gas valve.

N/S-Not shown