


OneTouch™ Control Panel



Key No.	Part No.	Description
1	R0550100	OneTouch, Faceplate Only, White
	R0550200	OneTouch, Faceplate Only, Black
	R0550300	OneTouch, Faceplate Only, Satin Chrome
	R0550400	OneTouch, Faceplate Only, Polished Chrome
	R0550500	OneTouch, Faceplate Only, Satin Brass
	R0550600	OneTouch, Faceplate Only, Polished Brass
2	R0551200	Screw, #6 × 3/8" Phillips Pan Head, Type BT (Purchase Kit #R0551200)
	4862	Washer, Buna N, 3/8" OD (Purchase Kit #R0551200)
3	R0550700	PCB Subassembly w/ White Buttons and LCD
	R0550800	PCB Subassembly w/ Black Buttons and LCD
4	R0550900	Housing, Flush Mount, White
5	3278	Screw, #6 × 1" Phillips Pan Head, Type A (Purchase Kit #R0551300)
	1325	Screw, #8 × 5/8" Phillips PN T-A (Purchase Kit #R0551300)
7	R0551000	Housing, Surface Mount, White
	R0551100	Housing, Surface Mount, Black
8	7953	OneTouch Control Panel, Complete, Surface and Flush Mount, White
	7954	OneTouch Control Panel, Complete, Surface and Flush Mount, Black
9	R0551400	Replacement Buttons, OneTouch, White
	R0551500	Replacement Buttons, OneTouch, Black
10	7684	Cleat, Flush Mount Sheet Rock Fastener (Purchase Kit #R0551300)
11	RO410200	OneTouch Controller Chip
N/S	R0551800	Service Controller, OneTouch w/ 3 ft. Cable and Connector
N/S	RO467100	Wire Harness w/ RJ45 Connector, Service Controller

N/S - Not Shown